

Product Name : Indentation Hardness Tester	Product Code : NLAB-TESTINGLABM56002
Description :	
Indentation Hardness Tester	
Technical Specification :	
Indentation Hardness Tester for rubberized coir cushioning is used for the indentation hardness measurement of foam, PU foam, rubberized coir and latex foam. The system consists of a shear beam type load cell over which the test specimen is kept. The test specimen is pressed with an indenter of the specified dimension mounted on self/ aligning ball bearing such that it can adjust its inclination to match the top face of the test specimen. The indenter can be moved down manually through a hand wheel (as well as by motor and gear box) and screw arrangement, thickness is measured on strip scale and Compression is measured on a digital indicator and the corresponding load is measured on the digital readout of the load cell.	

Naugralabequipments

Website: www.naugralabequipments.com, **Email:** sales@naugralabequipments.com

Address: 6148/6, Guru Nanak Marg,Ambala Cantt,Haryana,India. **Phone:** +91-9896600003